

Steam Mop Select

80K6, 94E9 Series

No Power

1. **Check the entire length of the power cord for damage.** If there is damage, please contact BISSELL Consumer Services.
2. **Make sure the unit is plugged into a functioning outlet.**
3. **Make sure the unit has had ample time to heat up before trying to steam mop.**
4. **If there is still no power,** please contact BISSELL Consumer Services.